HEAT EXCHANGER

SHELL & TUBE TYPE



- · The natural gas is heated in a shell and tube heat exchanger using a heating medium.
- Two separated fluids at different temperatures flow through the heat exchanger, one through the tubes and the other through the shell around the tubes.
- · A shell & tube heat exchanger consists of a number of tubes mounted inside a shell.

